

Gastgebruik Fritz!Box 7360

Het is verstandig bezoekers die van jouw WiFi gebruik willen maken een gast-toegang verlenen. Met de gast-toegang kun je alleen maar het internet op, niet het netwerk in.

Toegang tot de Fritz!Box wordt verkregen door in een browser het adres <http://fritz.box> in te tikken en te openen.

Als nu geen popup verschijnt die om een inlogcode vraagt, maar direct het "Overview"-scherm, dan is hier sprake van een onveilige situatie. Ga in dat geval naar hieronder: [Login password aanmaken](#)

Voer het password in en klik op Login

Het Overview scherm verschijnt.

Via menukeuze "Wireless" kies je voor "Enable Guest Access", vervolgens vink je "Guest access enabled" aan en vult het veld "Name of the guest radio network (SSID)" met een zelfgekozen benaming b.v. Fritz!Box gast of Mijn gast o.i.d. Voor de "Encryption" kies je WPA+WPA2 en voor de "Network key" een string die gemakkelijk te onthouden is, b.v. gastvanhenkeningrid o.i.d. en klik op de knop "Apply".

Login password aanmaken

Kies in het Overview scherm "System", selecteer "Fritz!Box Users" en kies dan tab "Login to the Home Network". Klik nu op Login with the Fritz!Box password, vul hier een unieke code in en klik op de knop "Apply".

The screenshot shows the Fritz!Box web interface. The top header is blue with the Fritz! logo on the left, and 'FRITZ!Box Fon WLAN ...', 'FRITZ!NAS', and 'MyFRITZ!' on the right. A navigation menu on the left lists various system settings, with 'System' expanded to show 'Fritz!Box Users' selected. The main content area is titled 'System > FRITZ!Box Users' and has three tabs: 'User', 'Login to the Home Network' (which is active), and 'Apps'. The 'Login to the Home Network' tab contains the following content:

Login for Access to the Home Network

Here you specify how to log in to the FRITZ!Box user interface when you are in your home network at home. Login is recommended for reasons of security.

☐ Login with FRITZ!Box user name and password

☒ Login with the FRITZ!Box password

When this option is enabled for the first time or re-enabled, a new FRITZ!Box password must be defined. To view the settings of this FRITZ!Box, to change the settings, or to access information, each user has to log in using a shared FRITZ!Box password.

FRITZ!Box password

Note:
Access to the FRITZ!Box is permitted only if the specified password is entered here. Be sure to keep it in a safe place.
If you have forgotten the password, you cannot open the user interface again until the factory settings have been restored to the FRITZ!Box. This operation will discard all FRITZ!Box settings.

☐ No login (not recommended)

Confirm

☒ Extra confirmation to configure certain settings and functions

Before configuring certain settings and functions, such as setting up a call diversion or an IP telephone, you will be prompted to enter a key sequence on a connected telephone (analog, ISDN or DECT) to confirm that you are an authorized user.

At the bottom right, there are 'Apply' and 'Cancel' buttons.

Belangrijk:

Berg de inlogcode goed op, want bij verlies kan alleen nog worden teruggegaan naar de fabrieksinstellingen.